



Inflatable Pad Owners Manual

Warning: Read carefully and understand all Assembly and Operation Instructions before operating. Failure to follow the safety rules and other basic safety precautions may result in serious personal injury. Do not allow persons to operate or assemble this PAD until they have read this manual and have developed a thorough understanding of how this PAD works. The warnings, cautions, and instructions discussed in this instruction manual cannot cover all possible conditions or situations that could occur. It must be understood the by the operator that common sense and caution are factors which the operator needs to follow.

GENERAL SAFETY

Watersports can be safe and fun for all. The owner manual is made to enhance your enjoyment of the use of this product. It is very important that you take time to read this owner manual. Make sure you understand the information in this manual prior to each use.

- Misusing the product may result in serious injury or death. Use extreme caution
- Inspect all equipment prior to use; Do not use if damaged
- Do not tow or attempt to ride this pad behind a boat or vessel
- This product is not designed for aerial tricks.
- Users must wear a Coast Guard Approved personal floatation device (PFD)
- This pad is not a life saving device
- Do not jump or dive off this product.
- Always use during safe conditions and beware of any changing conditions or windy conditions
- Do not use this product while under the influence of alcohol, drugs or medications
- Never use this product during dark conditions
- Use with adult supervision
- Do not use near other boat traffic or watercraft
- Do not use if you suspect a puncture or leak.
- Do not use in shallow water

- Use of this product must use caution and common sense at all times.

INFLATING TIPS AND PRECAUTIONS

Find a flat area to inflate and make sure the area is free of sharp objects, sticks, stones, etc.

- Carefully unfold and spread out across the floor.
- Do not drag across the ground as it might puncture from sharp objects.
- Locate the inflation valve and remove the protective valve cover.
- Press down on the spring valve and open the valve.
- Insert the inflation pump adapter to the valve. Secure the adapter by turning it clockwise
- Connect the pump to the adapter hose and inflate to 4-6 psi. Stand the pump on hard level ground. Place your feet on the footrest on the pump
- inflate in a
- When you have finished inflating the pad remove the pumps adapter hose and replace the valve cover. Pump time will take around 5-15 minutes
- We recommend that you inflate your pad to 5-7 psi until the pad becomes firm
- Do not over-inflate your pad, a max pressure of 7 psi is adequate
- Do not use an air compressor as it may cause damage to your pad due to over inflation
- There may be a small decrease in pressure due to changes in temperatures. If so, add a few pumps of air
- Never let your fully inflated pad sit out in the sun for a long period of time

DEFLATION TIPS

- When deflating your pad, make sure to clear any water or debris out of the valve area and slowly press down on the valve stem and there will be a loud burst of air
- Roll or fold the clean and dry pad starting from one end to the other end.

CONTROLLING SUNLIGHT EXPOSURE

The pad is manufactured with UV resistant PVC to provide superior protection from ultraviolet light but to ensure extra years of flexibility and bright colors avoid storing the pad exposed to the weather or in direct sunlight. Fading can happen when exposed to over exposure to the sun. Do not store your pad in a sunny location when not in use. Sunlight will harm your pad if exposed for extended periods of time.

STORAGE AND BOARD CARE

- Always store your pad in a cool dry location out of reach of direct sunlight
- When storing your pad for prolonged periods in deflated, it is best to keep it loosely rolled or folded
- Before storing, rinse off with fresh water and let it dry completely to prevent mildew buildup. Most dirt can be removed with mild soap and fresh water

LEAK DETECTION AND REPAIR

- If you are losing air pressure not caused by colder temperatures, check the pad for leaks starting with the valve. A leaking valve is rare. We have supplied in the repair kit a valve wrench, if the valve is loose. We could supply a replacement valve if it is found to be defective

- Small leaks can be easily found and repaired. Spray all around the board with a mix of liquid soap and water until air bubbles become visible
- The ParadisePad pad comes with a repair kit. Once a leak is found deflate the board and cut a round piece of repair material large enough to overlap the leak by 2". Round corners of the patch are less likely to snag. Apply the adhesive to the bottom of the patch and on the pad air leak area. Allow adhesive to become tacky then apply the patch. This is a contact adhesive and once the surfaces touch, you cannot reposition the patch, so be careful to align it before bonding the surfaces together. Roll the patch onto the pad surface to prevent a air bubble. Thoroughly go over the surface of the patch with a roller, edge of the valve wrench to apply pressure and ensure a solid bond. Apply a weighted object to apply pressure to the area for 12 hours. Do not apply full air pressure to the pad for 24 hours

LIMITED WARRANTY

ParadisePad provides a 2 year limited warranty on all pad products and warrants that these products are free of defects in materials and workmanship for the period of 2 years of the original owner of the SUP. After inspection, we find that this SUP failed due to a covered defect, it will be repaired or replaced at our option and you will need to cover shipping charges from the consumer to ParadisePad.

This warranty period for the board does not cover:

- Normal wear & tear including scratches, fading, cuts, tears or commercial use including rental
- Damage caused by abuse or failure to perform normal maintenance
- Damage caused Modifications or alterations
- Damage caused by submerged objects or beaching
- Damage caused by transportation, excessive heat or sunlight
- Damage caused by over inflation
- The warranty does not cover damage caused by improper use
- Damage caused by excessive load weights
- The original purchase receipt must accompany all warranty claims. The date of purchase and name of the retailer must be legible

ParadisePad does not extend any written or implied warranties beyond those expressly described herein. To the extent any provision of this warranty is prohibited by federal, state or municipal law and cannot be preempted, it shall not be applicable.

To receive more information regarding our warranty service, email info@paradisepad.com.