



General Use Instructions

Please read and understand how to unpack, anchor, maintain and store, and most importantly provide a safe environment for family and friends.

Unpacking your ParadisePad

Use care when unpacking the ParadisePad to avoid any cuts or damage to the pad. Do not use a knife or other sharp objects to cut the packaging material because it could possibly damage the surface. Make sure to always secure the rolled ParadisePad using the straps that were provided. The ParadisePad straps are designed to keep the pad rolled and are not designed to secure the pad to other objects.

Anchoring your ParadisePad

When choosing a location, place it in an area that has sufficiently deep water (approximately 8ft-10ft) and is free of obstructions above and below the water surface; this includes positioning your ParadisePad a safe distance (10ft) from hard surfaces or objects that someone could possibly strike if they were to fall off. ALWAYS use and fasten the bungee cord to the bottom of the water pad, connecting the stainless steel clip on the bottom side, and make sure it is not lifting or pulling the ParadisePad off the surface of the water. WE STRONGLY RECOMMEND ATTACHING THE BUNGEE CORD TO BOTTOM SIDE OF THE PARADISEPAD AND THEN ATTACHING THE OTHER END OF THE BUNGEE CORD TO AN ANCHOR (Depth may vary so consider attaching rope to the anchor, then to the bungee). When attaching your ParadisePad, there needs to be looseness on the rope/line; not doing so may cause damage to your ParadisePad and is not covered under our warranty.

General Safety Rules

WARNING: Never use this product in an area near running boat motors! Serious injury or death can result from contact with moving watercrafts. Use of this product involves risk of personal injury. Users accept responsibility for any and all inherent risk.

- Always consider the height and weight of the users of the ParadisePad, including the activities performed, when selecting a safe location
- **NEVER TOW** the ParadisePad behind any boat or personal watercraft
- Precautions should always be taken to eliminate activities that could possibly result in users to become entangled in lines or tethers
- It is recommended that all users wear an approved U.S. Coast Guard Personal Flotation Device (PFD) life vest before entering the water
- Children should be under adult supervision at all times
- Never enter the water or play on the ParadisePad alone
- Please do not use or attempt to swim to your ParadisePad while under the influence of alcohol or drugs, or are tired/fatigued
- Never dive off the ParadisePad head first in shallow water. We recommend entering the water feet first when getting off
- Do not attempt flips or any other acrobatic maneuvers without prior knowledge of proper technique. Such actions may cause serious risk of injury to oneself or others in area

- Never swim under the ParadisePad
- Do not jump from other objects onto the ParadisePad
- - Use only during daylight hours and in conditions where visibility is not an issue for or towards the user(s)
 - Never use in stormy weather, after sunset, or in rough surface water conditions
 - Use a highly-visible buoy if necessary to your location on the water
 - Please do not attempt to step from your ParadisePad directly onto a watercraft, dock, or other platform
 - Use extreme caution along with common sense while using your ParadisePad
 - When not in use, secure your ParadisePad from unauthorized or unsupervised use

Maintenance and Storage

It is recommended that you remove the ParadisePad from the water after each use. If you choose to leave it in the water for an extended period of time, we highly suggest you attach a visible buoy for passing traffic. By leaving your ParadisePad in the water for an extended period of time may allow water-borne particles or algae to adhere to the surface. Please use only a mild soap, water solution, soft clothe, as well as light pressure to clean the surface. HIGH PRESSURE HOSES AND/OR SCRUB BRUSHES CAN CAUSE DAMAGE not covered by the limited warranty. Before storage, make sure the ParadisePad is dry and free of foreign materials. **Do not dry your ParadisePad on your driveway or surfaces that feel hot in temperature to your skin/feet.** Roll the ParadisePad loosely and store it out of direct sunlight. Secure your ParadisePad with the Velcro straps that are provided.

Please keep this owners manual as well as proof of purchase from your boat dealer/marina in a safe location. They are essential when requesting a warranty inspection/return. The *one-year limited and conditional warranty* covers all defects encountered under normal use of this product and does not apply to the following cases:

- Loss or damage to the product due to abuse, misuse, neglect, accident and/or failure to follow maintenance, operating, and storage instructions
- Service or repair performed by a third party not authorized in writing by ParadisePad
- Wear and tear from normal use, weathering, or damage caused by sharp objects, heat, or animals
- Loss due to fading or degradation caused by an extended exposure to sunlight
- Loss or damage to the product due to being towed or incorrectly tethered
- Loss or damage from the product being exposed to excessive pressures created from jumping on it from other objects and/or from pressures created from constraining the product during use
- Loss or damage caused by improper storage or wet products resulting in rot, mildew, or like conditions

You assume all risk and liability for loss, damage, or injury to you and your property, as well as to others and their property, arising from the use, abuse, misuse or other actions taken with any product sold by ParadisePad.